

BL-2130C Manual

Adjusting the Angle of view



Please refer to www.brigade-electronics.com/brigadevan for more information and technical documents

Step 1

On the front of the camera, there are 2 screws either side of the camera lens, loosen these using a Philips head screwdriver *Do not fully remove.



Step 2

Once the screws are loose move the camera lens housing up or down, adjust to the preferred viewing angle and then tighten the screws.

